

BOLT TEMPLATE

Step 1

Make sure to print this page actual size. On your printer settings, SCALING should be turned OFF or set to 100%. Depending on your browser, you can check this setting by clicking File, then Print Preview. Make sure the scaling setting says 100%.

Step 2

For best results, print the BOLT TEMPLATE on thick paper or card stock.

Step 3

Cut out the BOLT TEMPLATE using an X-acto® knife or scissors.

Step 4

Remove your current bed rails from your bed.

Step 5

Does the bolt template line up with the holes on your headboard? If so, the rails should work for you.

