





Caster Wheels: Assembly Instructions

Parts Included

- Caster Wheels - 4
- Caster Inserts - 4



Instructions

- 1.) You can attach the caster wheels either during assembly of your bed frame or after already assembled. TIP: If bed frame is already assembled, make sure to remove any extra weight before attaching wheels.
- 2.) Place caster inserts into legs of bed frame.
- 3.) Insert metal stems into caster inserts.
- 4.) Press until wheel locks into place.

